

<b>T.I. no.: 2019 - 94</b> Updated: -	<b>Topic: Software 6.37.2</b>
--	-------------------------------

<b>Date: 14.10.2019</b>	<b>Priority</b>	<b>Need for action</b>
<b>Affected machines: JDE Barista Pro BF</b>	High	As soon as possible
<b>From serial number: 1936.../</b>	Medium	On next visit to the machine
<b>As of date: -</b>	X Low	X FYI only

## NEW FUNCTIONS AND IMPROVEMENTS IN 6.37.2

The following is an overview of the new functions and improvements:

### New functions:

- New translations (FI, FR, ZH-CN)
- New brands have been added
- A "Stop" button is displayed during beverage dispensing.
- Different beverage icons for different brands and sizes.
- Flavour can be assigned to the syrup pumps.
- Currency can be deactivated. The prices are then displayed without a currency symbol.
- A "backup" grinder can be assigned to the grinder. This is used to allow the currently selected beverage to be dispensed.

### Improvements:


- Various corrections and adjustments to the translations and brand texts.
- Process display with payment system adjusted.
- Syrup is no longer displayed separately in the beverage statistics for "special" beverages.
- If a bean hopper is empty, the blend is correctly displayed as "unavailable".
- GUI cup highlighting adjusted.
- Vanilla without sugar availability is displayed correctly.
- Error messages if boiler sensors fail are displayed correctly.
- "Restore master settings" works correctly.
- Numeric keyboard made smaller for price adjustment.
- Text for screen saver adjusted.
- Prices are also correctly displayed after manual adjustment.
- Beverage sizes are correctly displayed when the language is changed.

## "Stop" button during beverage dispensing




The [Stop] field is displayed while a beverage is being dispensed.

## Flavour can be assigned to the syrup pumps.



In the "Configuration" -> "Barista station settings" menu, the flavour can be assigned to the pump in parameters 24-27.

## Backup grinder



In the "Configuration" -> "General settings" menu, a backup grinder can be assigned to each grinder in parameters 28-30.

This makes it possible to dispense the beverage in any case. After dispensing, you are notified that there are no beans and the respective beverage is displayed as unavailable.