

T.I. no.: 2026-02 Updated: -	Topic: Software V5.66.5 Release Notes
--	--

Date: 3/06/2026
Affected machines: SOUL, SKYE
From serial number: -
From date: right away

Priority and need for action	
<input type="checkbox"/>	High: as soon as possible
<input checked="" type="checkbox"/>	Medium: on next visit to the machine
<input type="checkbox"/>	Low: FYI only

INFORMATION ON SOFTWARE UPDATE

New functions have been added and errors eliminated with software update V5.66.5. The platform software optimizes and replaces software version V5.48.8.

Overview of the most important new functions

- SKYE: BestFoam available with SuperSteam
- Configuration of an HCU simulation for the Soul NA
- Optimization of the completion dialog and replacement of the animation in the ProCare descaling process
- Additional note for reordering the red ProCare cleaning pouch after each descaling process
- Language settings extended with addition of Bulgarian and Croatian
- Platform extended to include a new **Tea with milk** beverage type
- Introduction of the **Coffee mix** function (**Half-caf**)
- Both syrup steps in a beverage recipe can now be optionally configured
- Prisma: Extension of cleaning log queries with time query & cleaning type filter
- Validation of sensor function prior to ProCare cleaning and pouch reconditioning
- Adjustment of ProCare refill volumes during milk cleaning
- Transfer of existing 50 beverage dispensing statistics using the Prisma interface
- Addition of supplementary data to the Prisma beverage dispensing statistics
- Support for importing CP files using the Prisma interface
- ProCare: Water flow and minimum measurement duration for the conductivity sensor integrated into the standard software
- Prisma: Extension of beverage dispensing statistics to up to 2,000 entries including time query
- Optimization of refill volume for pouches in ProCare

Corrections/Troubleshooting

- Correct display of the squeeze valve installation screen during commissioning
- Resolution of the filling/sensor error after Plug&Clean cleaning when **Late Milk Fill Up** is activated
- Interruption of the blue pouch replacement routine due to pulling on grounds container
- Automatic deactivation of nutritional information in Staff mode when switching modes
- Software crash after Plug&Clean cleaning
- Internal milk filling after milk cleaning without Plug & Clean improved
- Touch Freeze bug caused by blocked AHA fixed
- Bug related to selection of manual cleaning in the cleaning schedule at the Mandatory level fixed
- Correct status message and booking when conditioning a cleaning pouch
- Correction of range calculation for Uptime descaling
- Prisma: Correct display of calibration data in the maintenance menu

Service contact

Global Technical Support Team

GBU Professional Coffee Machines

- Support hotline: +41 32 681 62 75 (10:00-11:30 a.m. CET/3:00-4:30 p.m. CET)
- Support e-mail: technical-support@schaerer.com