

<b>T.I. no.:</b> 2024-05 <b>Updated:</b> -	<b>Topic:</b> Software V5.24.7 Release Notes
---	--

<b>Date:</b> 15.04.2024
<b>Affected machines:</b> SOUL, SKYE
<b>From serial number:</b> -
<b>Start date:</b> immediately

Priority and need for action	
<input type="checkbox"/>	High: as soon as possible
<input checked="" type="checkbox"/>	Medium: on next visit to the machine
<input type="checkbox"/>	Low: FYI only

## INFORMATION ON SOFTWARE UPDATE

New functions have been added and errors eliminated with software update V5.24.7. The platform software optimises and replaces software version V5.18.5.

### Overview of the most important new functions

- New parameters have been integrated in the **Cleaning** menu with the **Steam wand rinsing** (Clean & Purge) function.
- Dynamic language selection is possible.
- Telemetry is displayed as *active* when mobile payment or second screen is active.
- Remaining **ProCare** cleaning product (alkaline/acidic) is displayed as a per cent value.
- Descaling with **ProCare** is included in the remaining cleaning product calculation.
- **ProCare** is displayed correctly for the commissioning assistant.
- Cleaning bags are no longer refilled during **ProCare** cleaning when a limit value is undercut.
- New **ProCare** animations with TwinMilk option have been added.
- If more than two recipes are configured, an additional menu bar becomes visible on the right in Staff mode and in Frequent user mode.

### Corrections/Troubleshooting

- Unfounded flow meter errors have been fixed.
- Error resulting in machine inoperability due to the **Payment retry** function has been fixed.
- The button for cancelling a beverage is no longer greyed out after actuation.
- SKYE with internal tank without milk system with steam wand can no longer be configured.
- Syrup quantities are now transmitted to telemetry in millilitres instead of microlitres.
- **Plug&Clean** before the cleaning step is displayed correctly when **Switch off after cleaning** is activated.
- Incorrect text display when replacing the ProCare BLUE / ProCare RED cleaning bag has been fixed.
- Error resulting in the MR node being displayed on the SKYE in the component test although it is not present has been fixed.

### Service contact

Global Technical Support Team

GBU Professional Coffee Machines

- Support hotline: +41 32 681 62 75 (10:00-11:30 a.m. CET/ 3:00-4:30 p.m. CET)
- Support e-mail: technical-support@schaerer.com