

| | |
|---|--|
| T.I. no.: 2017 - 16 Updated: - | Topic: ABS buffer for side cooling unit |
|---|--|

| | | |
|-------------------------------|-----------------|------------------------------|
| Date: 24.08.2017 | Priority | Need for action |
| Affected machines: SCP | High | As soon as possible |
| From serial number: - | Medium | On next visit to the machine |
| As of date: - | X Low | X FYI only |

ABS BUFFER (074789) FOR SIDE COOLING UNIT

The milk level sensor does not work correctly in some side cooling units if the milk container is on the right side of the cooling unit.

In this case, the ABS buffer (074789) can be affixed to the right rear area of the side cooling unit. The milk container is then located farther to the left and is correctly detected by the sensor.

- ▶ Clean the adhesive surface.
- ▶ Pull the protective film of the adhesive from the rear side and affix the buffer.



In side cooling units from serial number 17250464, the sensor is reprogrammed to prevent this malfunction. The side cooling unit serial number is visible on the interior side.

(EN) This page is intentionally left blank.

(DE) Diese Seite wurde absichtlich frei gelassen.

(FR) Cette page est laissée vide intentionnellement.

(ES) Esta página se dejado en blanco intencionalmente.