

T.I. no.: 2018 - 07 Updated: -	Topic: ABS buffer for grounds container
---	--

Date: 23.04.2018
Affected machines: SC Soul
From serial number: 1808.../
As of date: -

Priority	
	High
	Medium
X	Low

Need for action	
	As soon as possible
	On next visit to the machine
X	FYI only

ABS BUFFER (074789) FOR GROUNDS CONTAINER

In some machines, the grounds container is not correctly detected if it is situated a bit too far to the right.

In this case, the ABS buffer (074789) can be affixed to the right rear area of the grounds container shaft. This presses the grounds container farther to the left and it is correctly detected by the sensor.

- ▶ Clean the adhesive surface.
- ▶ Pull the protective film of the sticker from the rear side and affix the buffer.

The ABS buffer is installed from S.N. 1808.../



(EN) This page is intentionally left blank.

(DE) Diese Seite wurde absichtlich frei gelassen.

(FR) Cette page est laissée vide intentionnellement.

(ES) Esta página se dejado en blanco intencionalmente.